

Programming Chart PCS V 7 Betty

Keep button pressed for	LED	Release button	LED	Selected mode	Selected by	Exit programming
5 seconds	---	SOS Function		LED flashes SOS or Alpin emergency Signal or Superflash		press button
10 seconds	red LED lights	Setup Dimm-level	red LED lights for 5 sec. yellow LED lights for 5 sec. green LED lights for 5 sec. blue LED lights for 5 sec.	3 step with RVLR 2 step 3 step stepless level	press button press button press button press button	automatically see low level automatically automatically
		if 2 step dimming was selected	red LED lights for 5 sec. yellow LED lights for 5 sec. green LED lights for 5 sec. blue LED lights for 5 sec.	low beam = 1% low beam = 5% low beam = 40% low beam = 60%	press button press button press button press button	automatically automatically automatically automatically
15 seconds	yellow LED lights	Setup capacity control	red LED lights for 5 sec. yellow LED lights for 5 sec. green LED lights for 5 sec.	Low Middle High	press button press button press button	automatically automatically automatically
20 seconds	green LED lights	Setup Power	red LED lights for 5 sec. yellow LED lights for 5 sec. green LED lights for 5 sec.	Economy-Modus 13 W Normal-Modus 17 W Power-Modus 22 W	press button press button press button	automatically automatically automatically
25 seconds	blue LED lights	Setup SOS	red LED lights for 5 sec. yellow LED lights for 5 sec. green LED lights for 5 sec.	SOS alpine emergency Superflash	press button press button press button	automatically automatically automatically
 = factory defaults						