

ROTLICHT

Owners Manual:

First charge the light!

Basics:

Double click = Turn on

Each additional click = Changes the light mode

Hold the button down = Turn off

Charging: Connect USB cable e.g. to a computer, red blinking = charging, green = full

Available light modes:

- Steady
- Blink
- Pulse
- Steady + Impulse



Adjust the brightness of each light mode:

Keep the button down until the little GREEN LED lights up ●

→ Let the button go and wait.

→ Rotlicht now runs through the 5 possible output levels.

→ Press the button at the output level you want.

The following dim levels are adjustable:

■ Factory Settings

Dim Levels	Runtime			
	Steady	Blink	Puls	Steady+Impulse
0.1W	30h	60h	-	25h
0.25W	12h	24h	24h	10h
0.5W	6h	12h	12h	5h
1W	3h	6h	6h	2:30h
2W	1:30h	3h	3h	-

Changing the additional functions:

Keep the button pressed until the small RED LED next to the switch lights up.

Let the button go at the setting you want (also shown on the backside of the ROTLICHT).

Functions:

- 1x ● = Light sensor off
- 2x ● = Light sensor on - low sensitivity
- 3x ● = Light sensor off - high sensitivity
- 4x ● = Brake light off
- 5x ● = Brake light on - low sensitivity
- 6x ● = Brake light on - mid sensitivity
- 7x ● = Brake light on - high sensitivity
- 8x ● = Double click on/off
- 9x ● = RESET to factory settings

Example: To switch the brake sensor off

Keep the button down until the red LED blinks 4 times. ●●●●

Let the button go → Brake light function is now disabled.

Used capacity: After switching off, the red LED will blink 1x for each 100 mA.

Example: 4 x blinks of red LED = 400mA used = battery about half full